



AEROTHAN[®] TUBE

ASSEMBLY INSTRUCTIONS

For any questions about assembly, please contact Schwalbe customer service or a Schwalbe specialist retailer.

Assemble Aerothan Tube only with tires of appropriate size!

Check the valve hole diameter of the rim.

Assemble only with valve holes up to \varnothing 6.5 mm (SV)! Aerothan Tube should not come into contact with tubeless sealants. If necessary, clean the tire and rim with a rag before assembly.

Always use a suitable rim tape.

Inflate Aerothan Tube before assembly. **Max. 0.3 bar/4.5 PSI.** Inflating to a high air pressure when not mounted may cause deformation and damage to the tube. **Note: Aerothan Tube should not wrinkle.**

Do not twist the valve when inflating for the first time.

Reassemble Aerothan Tube only with the same tire size.

Repairable with Schwalbe Glueless Patches.

